

Socket 6x 2

Lamp grain warm light 15cm x 1

Lamp grain pink light 15CM x 2

headlight Warm light lamp grain 15CM X 1

Colored light strip warm light (1 section)x 2

cob light strip Blue ×2{“

Cable 5CM×1

Usb power Cable &AA battery case

Building block parts

**Precautions (The content of the pictures appearing in this paragraph is for demonstration and not part of this set):**


**Wire above and below the building blocks**

The wires can be arranged between the boards and the boards or underneath the boards, but they need to be placed correctly between the studs











### **Install the light particles on the building blocks**

Please make sure they are placed correctly (yellow LED components exposed). You can place them directly on top of the block piece studs or in between.















### Connect the wire to the light bar

Be extra careful when plugging the wire into the strip connector, the plug can only be inserted in one way. Place the light bar with the illuminated side facing up, making sure the side of the plug exposed wire is facing down. If the plug is not easy to insert into the interface, do not force it in. so as not to damage the connector and plug.

### The correct connection method of the light bar







## Insert the battery into the battery compartment

Several battery compartments have different specifications, please pay attention to the positive and negative poles of the battery.

**AA battery box Correct battery installation**



**Button battery box (flat) battery correct installation method**



**Button battery box (round) battery correct installation**







Connect them together, turn on the power, and the test particles light up normally

## Plug and socket connection method


Align the "=" on the plug with the "=" side on the receptacle



The "=" on the plug  
can clearly see one  
side of the line





There are two silver  
dots next to the "="  
socket on the socket



equal sign equal sign







**All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.**


**The connection method between the USB Power Cord and Expansion Boards is as follows:**





**The USB Power Cord can be powered by phone chargers, power banks, etc.**

USB connectors to connect devices






When we test " Lamp Particles 15CM-Warm White", take out the bag labeled "Small Lamp Particles 15CM-Warm White". Take out one of the lights and connect it to the outlet. Turn on the power and the light will turn on normally as shown in the figure below.

Test each lamp according to this method. It is important to note that after the test, the lamp must be put back in the corresponding bag to avoid confusion of types.

If any component is not working properly, please contact us immediately.











## Installation Steps







































Colored light strip warm  
light (1 section) x 2




Tear off the adhesive backing and paste it to the location shown


















































Socket 6x 2











Remove the wire from the bag (the color is subject to the actual receipt and does not affect the installation)










Take out the warm white headlight grains, 2×2 transparent round building blocks


















Remove the small light particle pink light and 1×1 transparent hollow round bricks































Tear off the adhesive backing and paste the COB strip as illustrated












Install the other leg











The color of the line does not affect the installation


















Remove the power cord

